



312483

Operating instructions TE 35

Rotary Hammer Drill 3-Wire Grounded Construction

HILTI

General safety rules

1. WARNING!

Read and understand all instructions.

Failure to follow all instructions listed below may result in electric shock, fire and/or serious personal injury.

SAVE THESE INSTRUCTIONS

2. Work Area

2.1 **Keep your work area clean and well lit.** Cluttered benches and dark areas invite accidents.

2.2 **Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.** Power tools create sparks which may ignite the dust or fumes.

2.3 **Keep bystanders, children and visitors away while operating a power tool.** Distractions can cause you to lose control.

3. Electrical Safety

3.1 **Grounded tools must be plugged into an outlet properly installed and grounded in accordance with all codes and ordinances. Never remove the grounding prong or modify the plug in any way. Do not use any adaptor plugs. Check with a qualified electrician if you are in doubt as to whether the outlet is properly grounded.** If the tools should electrically malfunction or break down, grounding provides a low resistance path to carry electricity away from the user.

Applicable only to Class I (grounded) tools.

3.2 **Double insulated tools are equipped with a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install a polarized outlet. Do not change the plug in any way.** Double insulation  eliminates the need for the three-wire grounded power cord and grounded power supply system.

Applicable only to Class II tools.

3.3 **Avoid body contact with grounded surfaces such as pipes, radiators, ranges and refrigerators.** There is

an increased risk of electric shock if your body is grounded.

3.4 **Don't expose power tools to rain or wet conditions.** Water entering a power tool will increase the risk of electric shock.

This instruction need not be provided for tools classified watertight or splashproof.

3.5 **Do not abuse the cord. Never use the cord to carry the tools or pull the plug from an outlet. Keep cord away from heat, oil, sharp edges or moving parts. Replace damaged cords immediately.** Damaged cords increase the risk of electric shock.

3.6 **When operating a power tool outside, use an outdoor extension cord marked «W-A» or «W».** These cords are rated for outdoor use and reduce the risk of electric shock.

4. Personal Safety

4.1 **Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a tool while tired or under the influence of drugs, alcohol, or medication.** A moment of inattention while operating power tools may result in serious personal injury.

4.2. **Dress properly. Do not wear loose clothing or jewelry. Contain long hair. Keep your hair, clothing, and gloves away from moving parts.** Loose clothes, jewelry, or long hair can be caught in moving parts.

4.3 **Avoid accidental starting. Be sure switch is off before plugging in.** Carrying tools with your finger on the switch or plugging in tools that have the switch on invites accidents.

4.4 **Remove adjusting keys or wrenches before turning the tool on.** A wrench or a key that is left attached to a rotating part of the tool may result in personal injury.

4.5 **Do not overreach. Keep proper footing and balance at all times.** Proper footing and balance enables better control of the tool in unexpected situations.

4.6 **Use safety equipment. Always wear eye protection.** Dust mask, non-skid safety shoes, hard hat or hearing protection must be used for appropriate conditions.

5. Tool Use and Care

5.1 **Use clamps or other practical way to secure and support the workpiece to a stable platform.** Holding the workpiece by hand or against your body is unstable and may lead to loss of control.

5.2 **Do not force tool. Use the correct tool for your application.** The correct tool will do the job better and safer at the rate for which it is designed.

5.3 **Do not use tool if switch does not turn it on or off.** Any tool that cannot be controlled with the switch is dangerous and must be repaired.

5.4 **Disconnect the plug from the power source before making any adjustments, changing accessories, or storing the tool.** Such preventive safety measures reduce the risk of starting the tool accidentally.

5.5 **Store idle tools out of reach of children and other untrained persons.** Tools are dangerous in the hands of untrained users.

5.6 **Maintain tools with care. Keep cutting tools sharp and clean.** Properly maintained tools with sharp cutting edges are less likely to bind and are easier to control.

5.7 **Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the tools operation. If damaged, have the tool serviced before using.** Many accidents are caused by poorly maintained tools.

5.8 **Use only accessories that are recommended by the manufacturer for your model.** Accessories that may be suitable for one tool may become hazardous when used on another tool.

6. Service

6.1 **Tool service must be performed only by qualified repair personnel.** Service or maintenance performed by unqualified personnel could result in a risk of injury.

6.2 **When servicing a tool, use only identical replacement parts. Follow instructions in the Maintenance section of this manual.** Use of unauthorized parts or failure to follow Maintenance Instructions may create a risk of electric shock or injury.

Additional Specific Safety Rules:

101 **Hold tools by insulated gripping surfaces when performing an operation where the cutting tool may contact hidden wiring or its own cord.** Contact with a «live» wire will make exposed metal parts of the tool «live» and shock the operator.

102 **Wear ear protectors when using the tool for extended periods.** Prolonged exposure to high intensity noise can cause hearing loss.

Hilti TE35 Combihammer



Always wear ear protectors.



Always wear protective gloves.



Always wear safety glasses.



Protective earthing

This Product is
UL listed



Technical data

Input power:	830 W
Voltage (versions):	120 V
Input current:	7.2 A
Frequency:	50–60 Hz
Weight of machine:	4.95 kg / 10.9 lbs
Dimension:	460×110×200 mm / 18.1"×4.3"×1.8"
Speed under load:	0–620 r.p.m.
Hammering under load:	0–3720 blows/min.
Single impact energy:	3.8 Joules / 2.8 ft. lbs
Drilling diameter range in concrete:	6–40 mm dia. / 1/4"–1 1/2" dia.
Recommended diameter range:	12–25 mm dia. / 1/2"–1" dia.
Drilling performance in medium-grade concrete with 16 mm dia. drill:	up to 60 cm ³ /min. Δ 300 mm/min.
TE-T-T drill bit:	12–32 mm dia. / 1/2"–1 1/4" dia.
TE-T-GB drill bit:	40 mm dia. / 1 1/2" dia.
TE-T-BK percussion core bit:	50–90 mm dia. / 2"–3 1/2" dia.
Chuck type:	TE-T
Quick-release chuck for drill bits for wood and steel	
Chisels: pointed, flad, wide-flat, channel, mortar and joint chisels	
Automatic cut-out brushes	
Grounded construction	
With slip clutch	
Dust-tight enclosure, central lubrication	
Variable speed switch	
Side handle adjustable with depth gauge	

Right of technical modifications reserved

Do not use this product in any way other than as directed by these operating instructions. The respective regulations of your trade association and the enclosed safety precautions must be observed. The operating instructions should always be kept with the machine!

Please note before start-up

When in operation, the machine should be held securely with both hands on the grips provided. Always ensure that you work from a secure stance.

1. The electric supply must comply with the data printed on the machine's rating plate.
2. Do not exert undue pressure on the machine. This will not increase its performance. Just position the bit and guide it.

Read the enclosed general safety rules.

Lubrication of chuck

The chuck is not incorporated in the lubricating system of the machine. The drill bit connection end must be cleaned regularly and lubricated. Regularly with a small amount of Hilti grease.

Note: The use of TE-C chisels is not recommended.

Operating:

Fig. 1: Insertion of drill bit

Turn chuck to the left (symbol ◀). Insert the shank of the drill bit into the drill chuck. While pushing in the bit rotate it until it moves farther into the chuck. Turn chuck to the right and lock drill bit in place (symbol ▶).

Fig. 2: Rotary hammer drilling

Rotary hammer drilling in concrete, masonry and natural stone. Press the red lockbutton on the switching lever. Turn the switching lever to the "rotary hammer drilling" position (symbol ↻) until the lockbutton engages.

Fig. 3: Drilling without hammering action

Press the red lockbutton on the switching lever. Turn the switching lever to the "rotary drilling" position (symbol ↺) until the lockbutton

engages. In this position, the insert tool simply rotates with no hammering action.

Fig. 4: Chisel adjustment

Press the red lockbutton on the switching lever. Turn the switching lever to the "chisel adjustment" position (symbol ↔) until the lockbutton engages.

Fig. 5: Chiselling function

Secure the chisel in the desired position and select the chiselling function. Press the red lockbutton on the switching lever. Turn the switching lever to the "chiselling" position (symbol ↻) until the lockbutton engages.

Fig. 6: Changing the chuck

Turn chuck to the left (symbol ◀). Pull the sleeve forward and completely remove chuck. When attaching chuck, pull the sleeve forward and hold it there. Slide chuck onto guide tube as far as it will go. Release sleeve. Turn chuck until steel balls snap into place.

Note: When a quick-release chuck is used, the hammering action is not transmitted to the insert tool (drilling without hammering action). However, for smoother running with less vibration it is recommended that the "drilling without hammering action" position (fig. 3) is selected.

Fig. 7: Side handle / depth gauge

The side handle can be pivoted and clamped in any desired position. Release the side handle by turning the grip counter clockwise, set the desired drilling depth with the depth gauge and then lock the side handle in position by turning the grip in a clockwise direction.



Manufacturer's warranty – tools

Hilti warrants that the tool supplied is free of defects in material and workmanship. This warranty is valid so long as the tool is operated and handled correctly, cleaned and serviced properly and in accordance with the Hilti Operating Instructions, and the technical system is maintained. This means that only original Hilti consumables, components and spare parts may be used in the tool.

This warranty provides the free-of-charge repair or replacement of defective parts only over the entire lifespan of the tool. Parts requiring repair or replacement as a result of normal wear and tear are not covered by this warranty.

Additional claims are excluded, unless stringent national rules prohibit such exclusion. In particular, Hilti is not obligated for direct, indirect, incidental or consequential damages, losses or expenses in connection with, or by reason of, the use of, or inability to use the tool for any purpose. Implied warranties of merchantability or fitness for a particular purpose are specifically excluded.

For repair or replacement, send tool or related parts immediately upon discovery of the defect to the address of the local Hilti marketing organization provided.

This constitutes Hilti's entire obligation with regard to warranty and supersedes all prior or contemporaneous comments and oral or written agreements concerning warranties.

USA

Hilti, Inc.
5400 South 122nd East Avenue
Tulsa, Oklahoma 74146
Telephone (918) 252-6000

CANADA

Hilti (Canada) Limited / Limitée
6790 Century Avenue, Suite 300
CDN - Mississauga, Ontario L5N 2V8
Telephone (905) 813 9200

LATIN AMERICA

Hilti Latin America, Ltd.
5400 South 122nd East Avenue
P. O. Box 21148
Tulsa, Oklahoma 74146
Telephone (918) 252-6595